Steps to install the

BlueNAC-3000® USB Drivers

STEP 1.- Without connecting your BlueNAC-3000, download from the website http://www.bluenac3000.es the BlueNAC-3000® setup program and run on your computer (this program is valid for the Intercom Moto, RadioLink Module and Aviation Headset).

STEP 2.- First window of the program simply tells the program is go to be installed in your computer. Click Continue.

STEP 3.- Following window is the software EULA (End User License Agreement), so you can use freely under a number of terms listed. Read it carefully before accepting it and click "Next".

STEP 4.- Starts the drivers installation in your system.

STEP 5.- Windows warns us that can't verify the publisher of the driver software. It is a standard warning of caution should not worry. Click on "Install this driver software anyway".

STEP 6.- If you followed the steps above, the system will inform the successful installation of drivers on your system.

STEP 7.- Then connect the supplied USB cable between the unit and your computer.

STEP 8.- System prompts you that it has been found a new device connected and automatically installs the default Bluetooth Adapter drivers.

STEP 9.- Next step is to set the proper drivers developed by NAC-Intercom. Press the Windows button in your task bar and right click on "Manage" (Admin privileges needed).

STEP 10.- In the Computer Management, select "Device Manager" in the left menu, search for your "Generic Bluetooth Adapter" device, right-click and choose "Update Driver Software…"

STEP 11.- Begin the driver software installation by selecting "Browse my computer…" manually.

STEP 12.- Choose pick from a list of devices installed on your computer.

STEP 13.- In the compatible devices list click on the Nac-Intercom BlueNAC3000 and press "Next"

STEP 13.- It begins the installation process and, if everything goes normal, a Successful installation window appears. Sometimes Windows requires restarting to apply the changes. And that's it, installation complete!